


Parts Include:

- A- Table (1)
- B- Benches (2)
- C- Support Rails (2)
- D- Hex Bolts (12)
(Packed attached to Support Rails)
- E- Hex Wrench (1)




Maximum Weight Capacity
Table: 300lbs, Bench: 500lbs



Completely read the instructions before starting assembly.

Step 1:


Remove the benches and the support rails from the assembled package.



Remove the wrench and all the bolts (12) from the support rails.

Step 2:

Lift all legs (table and benches) fully upright. Make sure the legs are securely locked in place.




Step 5:

(Note: The support rails must be removed before the picnic table and benches can be folded for storage.)


Remove the 12 bolts that hold the legs to the rails.

(Put bolts and wrench in a small bag taped to the rails for safe keeping.)



Step 3:

Flip the table and benches upright, then insert the ends of the leg tubes into a pair of holes in a support rail.



If the tubes do not match-up perfectly with the rail holes, try a different pair.


Step 6:

To fold the legs, press the ends of the leg braces inward to unlock the legs.



Step 7:

Press legs firmly against the underside of the table and benches for compact storage.



Step 4:

Tighten the table and benches securely to the support rails using all 12 bolts and the supplied wrench.



Step 8:

The picnic table is now ready for storage.

