



Drink Mixers



Freestanding

928ADM1

Single Head

928ADM2

Double Head

928ADM3

Triple Head

Wall Mounted

928ADM1WM

Single Head



SAFETY

1. READ AND SAVE ALL INSTRUCTIONS.
2. This appliance is not intended for use by anyone under the age of 18.
3. To avoid electrical hazards, do not place the drink mixer in or near water or other liquid.
4. Do not place hands or any objects near moving parts while the drink mixer is powered on.
5. Always make sure the blending blade has stopped entirely before removing malt cup.
6. Always make sure the drink mixer is unplugged before cleaning or removing any parts.
7. Do not use outdoors.
8. Power cord should be tucked away safely and not touching any hot surfaces.
9. Never immerse your drink mixer into water or other liquids. Clean the exterior using a damp cloth.

SETUP & OPERATION

1. Remove the equipment from the packaging and inspect for any damages.
2. Prior to use, clean the drink mixer and malt cup by following the cleaning instructions on page 3.
3. After cleaning, find a spot to install the mixer close to an outlet.
For Freestanding Models: Place on a sturdy counter or table.
For Wall Mount Models: Use the supplied screws to securely fasten to the wall. Make sure that the unit is level.
4. Plug the unit into the wall socket.
5. Prepare your ingredients to mix inside of the malt cup included with the drink mixer.
6. When ready, turn the mixer on using the on/off switch.
7. Select desired speed.
8. Place cup against the activator switch located near the top of the spindle on the unit. The rolled edge of the cup can rest on the ledge to hold the cup in place during mixing.
9. Allow the spindle to mix the ingredients until desired end product has been achieved. Mixer will turn off when cup is pulled away from the activator switch.
10. When finished using the drink mixer, switch off and unplug the unit.

CLEANING

TO AVOID DAMAGE, DO NOT LIFT MIXER BY THE SHAFT!

CLEANING MIXER

DO NOT SUBMERGE UNIT IN WATER OR ANY OTHER LIQUID

1. Unplug the machine.
2. Remove malt cup.
3. Working from the top down, clean, rinse and sanitize the mixer housing including the spindle rod.

Note: DO NOT get any liquid inside the vents while cleaning.

Clean: Use a damp cloth and soap to remove soil and debris.

Rinse: Use a damp cloth and clean water to remove any excess soap.

Sanitize: Use a damp cloth and sanitizing liquid to sanitize all surfaces.

4. To clean the spindles, start by loosening any debris with a small brush.

Clean: Add 8 oz. of washing solution to malt cup and place into position on each spindle of the mixer. Plug the mixer in and run on high for a minimum of 2 minutes.

Rinse: Empty cup and add 8 oz. of clean water. Place back onto the mixer and run on high for a minimum of 2 minutes.


Sanitize: Empty cup and add 8 oz. of sanitizing solution. Place back onto the mixer and run on high for a minimum of 2 minutes.

Dry: Empty cup and place back onto the mixer and run on high for a few seconds. This will shake off any excess moisture. Do not rinse cup, spindle, or agitator after sanitation is complete. Allow all parts to air dry.

RECOMMENDED CLEANING PRODUCTS

PURPOSE	BRAND	DESCRIPTION
Cleaning		Strike All Purpose Cleaner/Degreaser
Sanitizing		QuikSan Food Contact & Surface Sanitizer
Cup Sanitizing		Kleen-Cup Sanitizing Cup

DIAGRAMS



EQUIPMENT LIMITED WARRANTY

Avamix warrants its equipment to be free from defects in material and workmanship for a period of 1 year. This is the sole and exclusive warranty made by Avamix covering your Avamix brand equipment. A claim under this warranty must be made within **1 year** from the **date of purchase** of the equipment. Only the equipment's original purchaser may make a claim under this warranty. Avamix reserves the right to approve or deny the repair or replacement of any part or repair request. The warranty is not transferable. Avamix Equipment installed in/on a food truck or trailer will be limited to a period of **30 days** from the original date of purchase.

To Make a Warranty Claim:

For Warranty Inquiries contact the location where you purchased the product:

- **WebstaurantStore.com:** Contact help@webstaurantstore.com. Please have your order number ready.
- **The Restaurant Store:** If you purchased this unit from your local store, please contact your store directly.
- **TheRestaurantStore.com:** Online purchases, call 717-392-7261. Please have your order number ready.

Failure to contact the designated location prior to obtaining equipment service may void your warranty.

Avamix makes no other warranties, express or implied, statutory or otherwise, and **HEREBY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.**

This Limited Warranty does not cover:

- Equipment sold or used outside the Continental United States
- Use of unfiltered water (if applicable)
- Avamix has the sole discretion on wearable parts not covered under warranty
- Equipment not purchased directly from an authorized dealer
- Equipment used for residential or other non-commercial purposes
- Equipment that has been altered, modified, or repaired by anyone other than an authorized service agency
- Equipment where the serial number plate has been removed or altered.
- Damage or failure due to improper installation, improper utility connection or supply, and issues resulting from improper ventilation or airflow.
- Defects and damage due to improper maintenance, wear and tear, misuse, abuse, vandalism, or Act of God.

Any action for breach of this warranty must be commenced within 1 year of the date on which the breach occurred. No modification of this warranty, or waiver of its terms, shall be effective unless approved in a writing signed by the parties. The laws of the Commonwealth of Pennsylvania shall govern this warranty and the parties' rights and duties under it. Avamix shall not under any circumstances be liable for incidental or consequential damages of any kind, including but not limited to loss of profits.

