



FOR COMMERCIAL USE

Please read all information provided below before using the bagel slicer. The blade is extremely sharp. Even though the bagel slicer makes bagel cutting safe, quick, and simple, practice caution when using this tool.

DIRECTIONS FOR USE

1. Grasp the top of the handle portion of the bagel slicer with one hand holding down on the base to separate the blade from the base.
2. Place the bagel into the base.
3. With the blade pointing downward, position the handle of the bagel slicer directly over the base. The handle portion will cover the base as you push straight down. Do so until the handle portion touches the base.
4. Lift the handle portion up while holding the base securely with one hand. Remove your perfectly divided bagel from the base. If the bagel sticks while removing the handle portion, use a utensil to push down on the bagel from above the blade.

RECOMMENDATIONS

- Slicing frozen or stale bagels will dull the blade on your bagel slicer. Make sure to thaw frozen bagels completely before slicing or slice them before freezing.
- Bagels may compress or become squashed during slicing if they are too moist, sticky, or steamy (such as freshly baked bagels). To ensure the easiest slicing, moist and sticky bagels can be toasted for a few seconds prior to slicing. It is advised to allow freshly baked bagels to cool off before slicing.
- Flavored bagels (everything, blueberry, etc.) may leave a sticky residue on the blade. To ensure your bagel slicer works at maximum efficiency, clean it regularly. Ingredients containing acid may cause staining. Occasional staining or scratches will not affect the performance of your bagel slicer.

CLEANING INSTRUCTIONS

- To clean your bagel slicer by hand, use warm, soapy water and a bottle brush. The blade is very sharp; never reach into the handle portion. Do not use metal pads, steel wool, or abrasive cleaners to scour the blade.
- Place on the top shelf when cleaning in the dishwasher. Use caution when removing from the dishwasher, so that you don't hit the blade.
- Keep out of reach of children. The bagel slicer is not a toy. It should never be used by children of any age without adult supervision.