




CARE AND MAINTENANCE / OPERATING INSTRUCTIONS


FOR WARRANTY SERVICE INFORMATION PLEASE CALL 1-866-531-6243.

For other parts or trouble-shooting service information, visit WWW.GLASSWASHERPARTS.COM or contact us at the Bar Maid Customer Service line at 954-960-1468


Congratulations on your purchase of the finest Glass Washer made. Bar Maid® machines are manufactured and tested to meet the toughest safety and sanitation standards. Please follow these instructions carefully. Failing to do so in some cases may damage the machine, cause injury to the operator and/or void warranty.



These caution marks are located throughout this guide and on your Glass Washer

 = Lightning flash within a triangle, is to alert the user of the presence of dangerous voltage that may create a risk of electric shock. Do not open cover. No user serviceable parts within.

 = The exclamation point within a triangle is to alert the user to:








- “Caution” important information regarding the care and use of this equipment
- “Warning” possibility of personal injury









 = Triangle with fuse symbol is to alert user to fuse type and rating

 = Power off
 = Power on





IMPORTANT SAFEGUARDS!! PLEASE READ THIS FIRST:

Follow these basic safety precautions when using electrical appliance to reduce the risk of fire, electric shock and/or personal injury

-  **WARNING:** “A” Model Upright machine motors are water resistant but NOT SUBMERSIBLE. Do not use “A” Model Upright machines in sinks or tanks where there is a risk of falling over or submersing the motor.
-  **WARNING:** Observe the water level labels on machines. Do not overfill tanks. Never fully submerge any Glass Washer motor.
-  **WARNING:** Special SS Model cord requires original replacement part available only from Bar Maid Corporation. Contact Bar Maid Corporation for replacement.
-  **WARNING:** Motors may get hot with extended use. Turn off when not in use.
-  **WARNING:** Plug unit **only** into a **GROUND**ED outlet that matches the voltage/cycle as listed on the motor. Outlet must be equipped with a UL/CSA approved ground-fault circuit interrupter (G.F.C.I.).
-  **WARNING:** Keep electrical cord clear of brushes and water.
-  **WARNING:** Switches and switch boxes (for SS Model) must **NOT** contact water. **ATTACH BOX TO A DRY LOCATION with screws provided.**

-  **DO NOT** operate machine out of water. DO NOT use any machine if the power cord or motor housing is cracked or damaged.
-  **CAUTION:** Ensure brushes are securely in place before turning machine on.
-  **CAUTION:** Use machine only for the purpose it was intended.
-  **WARNING:** Disconnect from the power source before servicing.
-  **WARNING:** Do not use if any parts are cracked, broken or leaking oil.
-  **CAUTION:** Do not attempt to open or service the Submersible (SS) motor. No user serviceable parts. Call Bar Maid Customer Service at 1-866-531-6243 for service assistance.
-  **CAUTION:** Use only genuine Bar Maid® replacement parts.
-  **CAUTION:** Keep machines upright!! Lying on side may cause damage.

OPERATING INSTRUCTIONS - ALL MODELS

-  **WARNING:** Place unit in sink and fill with warm water to the top of the lowest brushes or the water line label. Water must be comfortable to touch. Add a quality liquid "low suds" detergent such as Bar Maid® LoSUDS®. Granular (powder) detergents are not recommended as they can be abrasive and cause premature wear to gears and bearings.
-  **WARNING:** Plug machine into a grounded, G.F.C.I. (ground-fault circuit interrupter) equipped outlet. Test and reset. Turn machine on.
-  **IMPORTANT NOTE:** SS Model Submersible machines will heat water but are equipped with a thermal cut-off to protect from over-heating. Excessively hot water may cause the machine to shut off. If this occurs, drain sink and refill with only room temperature water. Wait 20 minutes for machine to cool down, test and reset the G.F.C.I. at the end of the power cord and then restart. If machine fails to start, test circuit breakers and/or receptacle.
-  For best results, wash one glass at a time. **Always** start the Glass Washer before placing glass over the brush. The center brush scrubs the inside of the glass while the four outside brushes wash the outside. If taller glasses are washed, a longer center brush can be used, (see Brushes). Rinse in fresh water in second sink, then in third sink sanitize the glass. Let drain.

CARE AND MAINTENANCE

A few simple procedures will help ensure a long, trouble-free life:

- 1** When closing for the day, drain sink and wipe off machine.
- 2** **LET WASHER DRY** overnight.
- 3** Once per month, carefully lift off rubber band that protects gear housing. Immerse machine in enough water to cover brushes and add a half cup of vinegar or bleach. Run machine for ten minutes, rinse thoroughly and replace band. Check overall condition. If any parts appear cracked or damaged, please call 1-800-526-5278 or 954-960-1468. Troubleshooting advice can also be found online at www.glasswasherparts.com.

Brushes, LoSuds, Sanitizers and Odor Inhibitor



BRS-732SG
the perfect brush for
Shot Glasses



BRS-930
for wide coffee pots
and pitchers



BRS-935
for narrow top
coffee pots



BRS-950
Margarita & Martini
glasses



BRS-980
4 inch Muffin Pan Brush



BRS-917SL, BRS-920SL
BRS-922SL
Universal Slotted Brush



BRS-976
BRS-976SL
9 inch Pilsner brush for
Pilsners up to 8.5" deep



BRS-1722
BRS-1720SL
Electric Glass Washer
Replacement Brush Set



DIS-202
Quaternary Sanitizer
Test Strips



DIS-302
Chlorinated Sanitizer
Test Strips



TAP-CAP
Keeps bugs out and helps
keep Taps more sanitary



DET-200
Detergent for electric
glass washers



DIS-201
Quaternary Tablet Sanitizer
for Kitchen and Bar,
3rd Sink & Surface



TAP-STRIP
Drip Tray
Odor Inhibitor

NEW! Complete Line of Bar Necessities!!



CR-1600



CR-655R



BMP-5100B



CR-5830CLR



CR-100P



CR-1347



CR-830W



CR-1400BLK-0



CR-1252W



CR-501BLK



CR-1261

Bar Maid now offers 100's of new Bar Tools and Accessories:

For complete product listings visit: WWW.BARMAIDWASHERS.COM

Bar Maid Corporation - 2950 N.W. 22nd Terrace • Pompano Beach, FL 33069 USA

WARRANTY

Bar Maid provides a 1 Year Limited Warranty from the date of purchase covering defects in materials and workmanship (except brushes). In the unlikely event that you have a problem with your Glass Washer, call our Customer Service line at 1-866-531-6243 with the description of the problem. We will then tell you how to fix the problem, or direct you to the Factory Authorized Service Center nearest you.

This warranty does not cover accidental damage, damage caused by abuse, damage caused by use contrary to the operating instructions or damage caused by using the machine for a purpose other than for what it was intended. This warranty is limited only to the cost of repairing or replacing the warranted equipment, at Bar Maid's discretion. The warranty card must be returned within 21 days of purchase to validate this warranty.



**For warranty and/or service information please call:
1-866-531-6243**

**For other parts or trouble-shooting service
information, visit:**

WWW.GLASSWASHERPARTS.COM

Bar Maid Corporation

**2950 N.W. 22nd Terrace • Pompano Beach, FL 33069 USA
954-960-1468 • WWW.BARMAIDWASHERS.COM**