

Content

Vinyl

Backing

Hi-Loft™

100% Polyester

Finishes

PERMABLOK™ PLUS+
ADVANCED VINYL PROTECTION

Characteristics

Bleach Cleanable (1:9)**

Cleanable

Denim Dye Cleanable

Water Resistant

Environmental

AB 2998 Compliant

Formaldehyde Free

No Biocides

No Flame Retardants

No Heavy Metals

Prop 65 Compliant

Performance

Anti-Static

(ASTM D-257)

CFFA-Healthcare 201B

Cold Crack -20°F

CFFA-6a

Stain Resistant

CFFA-142

Sulfide Stain Resistant

Fisher Body TM 31-12

Superior Abrasion

CFFA-1a / ASTM D-4157

100,000 Cycles, Wyzenbeek #10 Cotton Duck

UV Stability

Xenotest: AATCC TM 16-3 / NTC 1479 /

CFFA-2a - Blue Wool

1,000 Hours

Flame Retardancy*

California T.B. 117 - 2013

NFPA 260 - Cover Fabric - Class I

UFAC Fabric - Class I

*This term and any corresponding data refer to the typical performance in the specific tests indicated and should not be construed to imply the behavior of this or any other material under actual fire conditions.

Specifics

Weight: 27 oz.

Width: 54 in.

Roll Size: 30 yd.

Applications

☐ Automotive | RV

☒ Education

☒ Healthcare

☒ Office

Hospitality

☒ Hotel | Motel | Casino

☒ Restaurant

☒ Public Spaces

Marine

☒ Interior

☐ Exterior

Residential

☒ Interior

☐ Exterior



This fabric meets or exceeds these ACT performance guidelines.

*Certification Marks owned by ACT®

CFFA CHEMICAL FABRICS & FILM ASSOCIATION, INC.

PERMABLOK PLUS+ CLEANING GUIDE



We recommend cleaning at least once a week to extend the lifespan of the upholstery, which will prevent dirt and contamination buildup and permanent staining. In the event of a spill, wipe off any excess right away with a dry white cloth or fabric, but be careful not to spread onto the remaining surface.



Clean the whole surface in a circular motion using liquid hand soap (pH neutral) and water (1 part soap to 9 parts water). Check the Approved Cleaners guide for recommended cleaning products. Wipe with a clean damp cloth to get rid of any excess soap. Repeat as needed and then let dry.



If there is any buildup that cannot be removed with soapy water, a mixture of 1 part isopropyl alcohol to 9 parts water can be used as a last resort. (Remember, using alcohol on a regular basis can affect the properties of the product.)



Once a month, you can use a soft-bristle brush for a deeper cleaning. Remember, light colors need more care, more often.

Note: The cleaning products recommended were used in a laboratory testing. Spradling Group® has no relationship with the manufacturers of those cleaning products.

**Disinfectants

In addition to cleaning, healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There are a wide variety of available biocides that include bleaches, peroxides, and quaternary ammonium products, among others. They should always be used at the recommended dilution; never in concentrated form. To prolong the life of coated fabrics, the disinfectants should be rinsed off after each use. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling International, Inc.® continually evaluates cleaners/disinfectants, and a list of those tested can be found on our website.

Abrasion test results exceeding ACT Performance Guidelines are not an indicator of product lifespan. Multiple factors affect fabric durability and appearance retention.

Permablok® Plus+ is a registered trademark of Spradling Holdings, Inc.
Whisper™ Neo Plus is a trademark of Spradling Holdings, Inc.

©2023 Spradling International, Inc.®

1/2023

UNITED

SINCE *Fabrics* 1946



New Jersey Headquarters:

9115 Pennsauken Highway
Pennsauken, NJ 08110
800.347.8344
www.unitedfabrics.com
sales@unitedfabrics.com

California Warehouse:

3260 E. 59th Street
Long Beach, CA 90805
800.472.4567
sales@unitedfabrics.com

