



CARE FOR CAMBRO® DOLLIES & CARTS

CLEANING INSTRUCTIONS:

- Clean with a soft cloth, bristle brush and a mild commercial detergent. Sanitizing solutions are recommended.
- **Do not use steel wool, abrasive pads, brushes, or any cleaners containing ammonia or bleach.**
- Rinse with clean, hot water.

TO REMOVE ANY LINGERING SCENTS AND STAINS:

Use an odor removing soak or sanitizer to remove scents and stains that can occur from holding products with strong odors.

- A diluted solution of 2-3 tablespoons of baking soda per gallon of hot tap water or 1 part lemon juice or vinegar to 4 parts hot water is also an effective way to remove lingering odors.
- Rinse thoroughly with hot water and dry.

CASTER MAINTENANCE

To be performed after unit has been washed or steam cleaned:

1. Grease swivel raceway of caster using a lubricant such as Lubriplate No. 930-AA, Keystone #84EPXLT multi-purpose grease or the equivalent. Moving "O" Ring or seal with finger, apply grease using a grease gun with a needle nose adapter or a tube-type applicator such as "Sta-lube" Moly-graph Assembly Lube. These can be obtained at most auto parts stores.
2. Use a light oil such as WD-40 on the nylon bushing at the hub. Check caster for any damage and test caster spin and swivel rotation before returning to service.