

Hazard Statements



WARNING - To prevent personal injury.

USER SAFETY

WARNING - Child Supervision

Unsupervised children may misuse the product, leading to potential injury or damage to the unit.

Children should be supervised to ensure that they do not play with the product.

Do not allow children to operate the product without proper supervision.

Initial Setup

Important Notes: Understand these guidelines for safe and effective use.

Do Not Use if Damaged: Check that the unit is not damaged (broken attachments, cracked frame, or missing components). Do not use if damage is found.

Inspect the Packaging: Examine the unit's packaging for any signs of damage that may have occurred during shipping.

Unboxing: Open the packaging with care.

- Use scissors or a box cutter to cut open the box.
- Ensure you do not damage the unit or its components.
- If any damage is noticed, contact customer service immediately.

Glove Dispenser: Dispensers are designed to accommodate different box sizes and brands.

Cleaning

Clean the Outside: Wipe the dispenser clean with warm water and mild soap. You can also use disinfecting wipes.

Avoid Harsh Chemicals: Do not use bleach or ammonia-based cleaners on plastic or acrylic dispensers.

Keep Away From Heat: Keep the dispenser away from direct sunlight and extreme heat.

Inspect the Mount: Check the screws or magnets once a month to make sure the dispenser stays securely on the wall or metal surface.

Installation

Installation Review: Carefully review the manufacturer's instructions for your product before beginning installation.

- If your dispenser has a magnetic feature, follow the "**Magnetic Installation**" instructions.
- If your dispenser is wall-mounted and came with provided hardware, follow the "**Wall-Mount Installation**" instructions.

MAGNETIC INSTALLATION

Warning: Magnets can be harmful to pacemaker wearers.

Clean the Area: Clean the metal surface with a damp cloth to remove dust or grease so the magnet sticks tightly.

Check Your Surface: Test a magnet on your desired surface.

Attach the Holder: Place the magnet gently against the metal surface. Make sure it is straight.

WALL-MOUNT INSTALLATION

Mark Hole Locations: Using a pencil, mark a spot in the center of the smaller top portion of the keyhole slot (Fig. 1).

Drill Pilot Hole: Using an appropriately sized drill bit, drill through drywall (and stud, if present) at the marked location (Fig. 2).

Install Hardware: Using hardware rated for the mounting surface, attach screws to the wall, leaving a ¼" gap from the wall (Fig. 3 and 4).

NOTE: Hardware included is only suitable for installation into studs and / or drywall. For other surface types, different hardware is required.

Hang: Hang the unit by lining up the pre-drilled holes on the back of the dispenser with the installed mounting hardware (Fig. 5).

