





## Scale Calibration for L-EQ 5/10 & 10/20

1. Turn on the scale and during the initial countdown/dashes press the     keys in that sequence. (QUICKLY AS POSSIBLE)


2. After countdown sequence is complete enter the password:


100100 = to calibrate in KG

100101 = to calibrate in LB

 = 0 &  = 1

3. After entering the password, press the  key.

4. If the password is correct the display will read RZERO (zero reference); with the scale being free of any weight press the  key.

5. Next the RLOAD (load reference) message will be displayed, place the maximum weight capacity and press the  key, wait until the countdown is finished.  
(5 to 0)

6. Remove the weight, turn off and Power ON the scale. The scale should be calibrated and now check for accuracy.