

QUICK START GUIDE



► How to use

A Product Features



BLEND AUTOMATIC

Blend more conveniently with automatic opening, automatic vacuum, and quick start functions.



BLEND DIFFERENT

Experience a differentiated recipe and a differentiated Asymmetrical Container with a blade made of STS material.



BLEND CUSTOMIZE

Create your own dreamed drink recipe by setting your own blending algorithm.



 $\ensuremath{\,\mathbb{X}}$ The product manual QR code is located to the right side of the Sound Enlosure.

B How to Use Each Function

Order	Features	Button	Control Panel		
1	Start/Stop	►II			
2	Pulse	٨-	Kuving's		
3	Display	WELCOME KUVINGS			
4	Manual Speed Control	• -	AUTO VACUUM BLENDER		
5	Auto Blending	1 2 3 4 5	1 2 3 4 5		
6	Auto Open/Close		5 6 7		
7	Auto Vacuum				





QUICK START GUIDE

Auto Open/Close



If you press the 'Auto open/close' button in the power standby state, the 'Auto open/close' mode is activated.

* When the Sound Enclosure opens and closes automatically, do not press or open the cover by force. (It may cause malfunction or damage.)



Auto Vacuum

If you press the 'Auto Vacuum' button in the power standby state, the 'Auto Vacuum' mode.

- * In the 'Auto Vacuum' mode, the backflow prevention mode is activated and the vacuum-related functions cannot be used continuously.
- * In order to reuse the 'Auto Vacuum' mode and related functions, separate the container completely from the body, then reattach it.



Quick Start Button

If you press the 'Quick satrt button' in the power standby state, the quick blending function is activated.

* Quick blending operates the function set in Auto Blending

Setting	Order	Details	Display
Vacuum	1	Press the 'Auto Vacuum' button and the 'Manual Speed Control' button (up/down) at the same time.	VACUUM SET UP
Pressure Setting	2	When the setup screen appears, use the 'Manual Speed Control' button to set the desired vacuum pressure.	
(Refer to p.27)	3	After setting the vacuum pressure, press the 'Start/Stop' button to complete the setting.	COMPLETED
	1	Press one of the 'Auto Blending' buttons 1 to 5 and one of the manual speed control up/down buttons at the same time.	RECIPE 01
Auto Blending Recipe Program	2	When the recipe setup screen appears, use the 'Manual Speed Control up/down' buttons to select the recipe program you want to set.	
Settings This is a method to select and input a program among 35 recipe programs.	3	After selecting the recipe program, press the 'Auto Blending' (1~5) button you want to set up. (ex. Press button 4 for use recipe program 05. "RECIPE 05 -> BUTTON 04" is displayed on the screen.)	Set recipe program 5 on auto blending button 4
(Refer to p.21)	4	Recipe setting is completed by pressing the 'Start/Stop' button. If "COMPLETED" appears on the screen, the selected program has been entered.	COMPLETED
	1	Press the two speed control buttons (up/down) at the same time. Then use the manual speed control buttons(up and down) to enter DIY recipe mode. After entering, press button 1 to DIY recipe The setting screen appears.	BUTTON 1 TO DIV RECIPE SET
	2	From section 1 to section 5, you can set the time and RPM for each section. * You can register from number 36 to 40, for your desirable program. Also you can edit/change, and you can add a total of 5 DIY recipes.	DIV BECIPE 38 = 5= M A1 = 25= 38 = 4= 5= P 011 022 033 044 055 T 011 022 003 004 005
DIY Recipe Program Settings	3	Select the DIY recipe number you want to register/change with the 'Auto Open/Close' or 'Auto Vacuum' button. (The text displayed at the top of the screen is "DIY RECIPE NO" / ex. DIY RECIPE 36)	DIV RECIPE 36
(Refer to p.26)	4	To move to the section you want to set (1~5), select using buttons 1~5.	10 2 3 4 5
	5	Select the setting item with the Pulse button. * M : Pulse (^1^) / Blending (1=1) mode, P : Rotation speed selection T : select operating time	P 011 022 003 004 005
	6	Press the 'Start/Stop' button to complete set up. The screen will display "COMPLETED". * If you want to cancel the setting, press Pulse button for 2 seconds.	COMPLETED

AUTO VACUUM BLENDER 11EN222009A