



Measured Liquor Pourer Care Instructions

Before use: Soak in warm, soapy water for 10 minutes. Rinse in cold water.

To install: Wet cork and push the Measured Pourer straight into the bottle.


To remove: Twist and pull straight up out of the bottle.

To pour: Hold bottle at approximately 45° angle when pouring. Do not “whip” or “baby” the bottle into pouring position. When bottle is low, allow liquor to reach the neck of bottle before tilting to 45°.

To wash: Soak in warm, soapy water. Rinse in cold water. For best performance, wash at least once a week.

Measured Pourer is designed to pour liquor only and will not pour accurately when pouring water, lemon, sugar, etc. Not recommended for cordials.

If cork fins flatten, run the corks under hot water for approximately 30 seconds, then run under cold water. This will straighten the fins.



HAND WASH ONLY
DO NOT RUN THROUGH DISHWASHER OR WASH IN EXTREMELY HOT WATER