



Compact Digital Portion Control Scales





334PC32	334PC10	334PC20
2 lb.	10 lb.	20 lb.



AVATEK Compact Digital Portion Control Scales

Specifications

Model		334PC32	334PC10	334PC20
	OZ.	32 oz. x 0.001 oz.	176 oz. x 0.001 oz.	352 oz. x 0.01 oz.
	lb.	2 lb. x 0.001 lb.	11 lb. × 0.001 lb.	22 lb. x 0.001 lb.
Capacity / Division	lb.:oz.	2 lb. x 0.1 oz.	11 lb. × 0.1 oz.	22 lb. x 0.1 oz.
	kg	1 kg x 0.00 1kg	5 kg x 0.001 kg	10 kg x 0.001 kg
	g	1000 g x 0.5 g	5000 g x 0.5 g	10000 g x 0.5 g
Weighin	g Units	lb.: oz., lb., oz., kg, g		
С	Display Display with white backlight		ight	
Operating	g Temp.	41 - 104°F (5 - 40°C)		
	Power	Alkaline Batteries: (2) "AAA" (not included) Adapter: 6V adapter (included)		
Fur	nctions	Weighing, Tare, Unit Switching, Low Battery $\&$ Overload Indication, Auto-Off Function		
Auto-O	ff Time	5 minutes with battery, none with adapter		
Tare	Range	Up to full capacity		
Platfor	m Size	6" × 6" / 152 × 152mm (L × W)		
Base Dime	Base Dimensions 8.75" x 6.1" x 1.1" / 222 x 155 x 28mm (L x W x H)			xH)

Control Panel



Function Keys

Keys	Definition	
POWER	Turn the unit On or Off.	
UNIT	UNIT Select weight unit of measure.	
TARE	Tare the weight.	



AVATE Compact Digital Portion Control Scales

Setup

Battery Installation and Power Supply

The scale can be powered with (2) "AAA" batteries or an external power supply. NOTE: Batteries and power supply can be used at the same time. If used simultaneously, the external power supply will be prioritized. The power supply will not charge the batteries.

Operation

Power On

- Place the scale on a hard, flat, and level surface.
- Press the **POWER** key to power it on. It will display "-188888", then "0.000lb."

Normal Weighing

- Place the object on the center of the platform. The scale will display the weight of the object when reading is stable.
- Press the **UNIT** key to switch between metric and imperial units.

Tare Function

- Place an item on the scale and wait for a stable weight.
- Press the **TARE** key to zero out the weight of the item.

Power Off

- When the scale is powered by batteries, it turns off automatically after (5) minutes of inactivity.
- When the scale is powered by an adapter, press the **POWER** key to power it off.

Cleaning & Storage

- Dampen a cloth with a mild soap solution to clean the scale.
- Do not use any harsh chemical cleaners.
- Do not wash down or immerse the scale. Any liquid inside the scale can cause permanent damage.
- Remove batteries from the scale when it will not be used for an extended period of time.

NOTE: Save these instructions for future reference.