




Instruction Sheet



PROGRAM TIMES

1. Press PROGRAM. The time will blink in the first box.
2. Use the + and - to adjust the time up or down.
3. Press the arrow to move to the next box.
4. Repeat step 2.
5. To change a day of the week to CLOSED, press the arrow until time is flashing on the day of the week that you want set to CLOSED. Press the CLOSED button.
6. Press PROGRAM to complete the programming process.

