



EZ1™ DRAINAGE SERIES

EZ1™ FLOOR DRAIN INSTALLATION INSTRUCTIONS

⚠ Warning: Flying material can cause eye injury or blindness and sharp edges could cause cuts or lacerations. Wear safety glasses and gloves when installing or working on drain.

1. Cut pipe so that the height of the finished drain is at or just below the height of the finished floor. (See Zurn Engineering Handbook or EZ1™ Submittal for dimensional heights). Ensure pipe is cut square and free of burrs or debris. See Fig. 1




Fig. 1

2. Install drain body on pipe and pressure test connection per local code requirements. See Fig. 2 (Neo-loc body shown for reference)

Note: All plastic bodies to be solvent welded to pipe




Fig. 2

3. Pour the rough floor slab flush with the top of the drain body.

See Fig. 3




Fig. 3

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

⚠ ADVERTENCIA: Cáncer y daño reproductivo - www.P65Warnings.ca.gov

⚠ AVERTISSEMENT: Cancer et effets néfastes sur la reproduction - www.P65Warnings.ca.gov

4. Install the waterproofing membrane per the manufacturers instructions. See Fig. 4

Secure the clamp collar to the body with the supplied 3/8-16 x 3/4 hex washer head cap screw. (Do not overtighten, Max. torque 8 ft-lbs [11 Nm])

Note: Clamp collar can be inverted for a lower rough-in height.




Fig. 4

5. Install rough-in cover assembly into clamp collar.

Adjust rough-in cover assembly so the top of the rough-in cover is at the finish floor grade. See Fig. 5

⚠Note: Ensure rough-in cover is tight to the concrete shield so no concrete seeps into the assembly





Fig. 5

6. Pour finish floor slab flush to the top of the rough-in cover.

See Fig. 6

Note: If fixture is above floor surface, it is recommended to hand finish concrete around fixture to avoid damage.




Fig. 6

7. Hit the top of the rough-in cover with a pair of adjustable pliers to loosen bond with the concrete. Continue hitting the rough-in cover until a visible crack forms around the entire circumference of the rough-in cover. Rough-in cover should appear loose (separates up from concrete). See Fig. 7

Note: Be careful to not hit the finished concrete floor as it will chip/damage the finish. Only hit the plastic rough-in cover. Do not use excessive force.




Fig. 7

8. Break the protective label in the center of the rough-in cover to expose a slot. See Fig. 8

Note: Do not remove entire label. Longer screws and adjustment shims are packaged under the label.




Fig. 8

9. Placing the back of the adjustable pliers head in the slot, unscrew the rough-in cover assembly counterclockwise until the tabs of the rough-in cover are above the concrete.

See Fig. 9





Fig. 9

10. Remove rough-in cover. See Fig. 10

Note: Do not discard the rough-in cover. Longer screws and adjustment shims are under the label and may be needed to adjust for a tilted drain.

For Slab On Grade Installation (Steps 11 and 12)

If finished fixture is tilted, See Step 15

Round

- 11a. Place a bead of silicone around the circumference of the last thread of the head assembly. See Fig. 11R
- 11b. Thread head assembly down until bottom of the frame is flush with the top of the concrete. See Fig. 11R
- 11c. Place a bead of silicone around the perimeter of the strainer frame. See Fig. 11R
- 12. Turn head assembly clockwise until top of strainer is flush with the finish floor. Wipe away excess silicone. Remove protective label once construction is complete. See Fig. 12R

Square

- 11. Turn head assembly clockwise until top of strainer is flush with the finish floor. See Fig. 11S
- 12. Fill in shroud with cement or grout. Ensure to completely fill in around entire head assembly flush with finished floor. Remove protective label once construction is complete. See Fig. 12S




Fig. 11S




Fig. 10




Fig. 11R




Fig. 12R




Fig. 12S

For Tile Installation (Steps 13 and 14)

If finished fixture is tilted, See Step 15

Round

13. Adjust head assembly to the height of the finished floor.
See Fig. 13R

14. Install finish flooring per manufacturers instructions.

Remove protective label from strainer once construction is complete.

See Fig. 14R




Fig. 13R




Fig. 14R

Square

13a. Adjust head assembly to the height of the finished floor.
See Fig. 13S

13b. Fill in shroud with cement or grout. Ensure to completely fill in around entire head assembly flush with finished concrete. See Fig. 13S

14. Install finished flooring per manufacturers instructions.

Remove protective label from strainer once construction is complete.

See Fig. 14S




Fig. 13S




Fig. 14S

For Correcting a Tilted Drain (Steps 15, 16 and 17)

15. Remove strainer and strainer frame from installed head assembly.

See Fig. 15




Fig. 15

16. A shim set and longer screws are included under the label of the rough-in cover.

Install shims on shank and adjust/rotate shims as needed to bring strainer level with the finished floor. (Included shims can adjust for up to 1/4" [6 mm] of tilt. See Fig. 16




Fig. 16

17. Reinstall strainer frame and strainer. Use included longer screws as needed. Torque screws to 16-18 in-lbs [18.5-20.5 cm-kg]

Remove protective label from strainer once construction is complete. See Fig. 17a for Slab on Grade Installation and Fig. 17b for tile installation




Fig. 17a




Fig. 17b