Use & Care Guide





ASSEMBLY/ARRIVAL

- It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
- 2. Inspect table top for damage before use.
- 3. Please refer to any safety labels on packaging or resources that come with table top.
- 4. Always follow cleaning and maintenance instructions.
- Assembly, if applicable, should be conducted by a qualified adult using the applicable instructions

STORAGE

1. After assembly, do not store upside down.

ONGOING MAINTENANCE

 Inspect all welds and fasteners on tables for damage before use. Ensure all legs are straight and touching the floor.

MONTHLY

 Tighten all bolts and screws, ensure structure is sound and there are no cracks/breaks in material. Do not overtighten – this may result in cracks in the material.





CLEANING INSTRUCTIONS

METAL PARTS

- Clean using a solution of mild soap or detergent with warm water. Recommended: Noble Lemon Lance (147LMNLANRQT).
- For dried-on dirt, clean with a soft brush and a mild cleaner. Recommended: Noble Spiffy Shine (999SPIFSHINE).
- Make sure metal is fully dry and clean before use to prevent rusting and other discoloration. As these may be the result of misuse, they may not be covered under warranty.

WOOD PARTS

- 1. Do not use abrasive cleaners or products.
- Use a clean, soft cloth to dust furniture weekly. Dust in the direction of grain to prevent visible scratching.
- Clean with a mild soap and damp cloth and dry with a dry cloth. Recommended: Noble Sunbright (999SUNBRIGHT) and for deep cleaning, Noble LusterPlus (148LUSTER+).
- 4. If you are using a new soap or cleaner, test first on an area that may not be shown.
- 5. Make sure wood is fully dry after cleaning and before use to prevent warping or damage to the finish. As these are the result of misuse, they may not be covered under warranty.

CAUTION

Ő

- 1. Always make sure table is stable and balanced.
- 2. Avoid scraping with sharp items/utensils.
- 3. Do not use if parts are broken or missing.

Use & Care Guide



ASSEMBLY/ARRIVAL

- It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damage must be reported to your authorized retailer within 5 days of receipt.
- 2. Assembly, if applicable, should be conducted by a qualified adult using the applicable instructions.

STORAGE

戸

1. Do not store upside down.

ONGOING MAINTENANCE

- 1. Use a clean, dry cloth or a soft duster to dust weekly.
- Inspect all welds and fasteners on chairs and barstools for damage before use. Ensure all legs are touching the floor.
- 3. Do not use if any parts are damaged or missing.

MONTHLY

- Tighten all bolts and screws, ensure structure is sound and there are not cracks/breaks in material. Do not overtighten - this may result in cracks in the material.
- Moving parts, such as barstool swivels, should be oiled regularly. Use a product such as Noble Lubriquick (999LUBRIQUIK) to avoid damage to the finish and premature wear on the parts.





METAL PARTS

CLEANING INSTRUCTIONS

- Clean using a solution of mild soap or detergent with warm water. Recommended: Noble Lemon Lance (147LMNLANRQT).
- For dried-on dirt, clean with a soft brush and a mild cleaner. Recommended: Noble Spiffy Shine (999SPIFSHINE).
- Make sure metal is fully dry and clean before use to prevent rusting and other discoloration. As these may be the result of misuse, they may not be covered under warranty.

WOOD PARTS

- 1. Do not use abrasive cleaners or products.
- 2. Use a clean, soft cloth to dust furniture weekly. Dust in the direction of grain to prevent visible scratching.
- Clean with a mild soap and damp cloth and dry with a dry cloth. Recommended: Noble Sunbright (999SUNBRIGHT) and for deep cleaning, Noble LusterPlus (148LUSTER+).
- 4. If you are using a new soap or cleaner, test first on an area that may not be shown.
- Make sure wood is fully dry after cleaning and before use to prevent warping or damage to the finish. As these are the result of misuse, they may not be covered under warranty.

CAUTION

1.

Ŋ

- Chairs and barstools are intended to be used indoors on a stable and level surface. Do not use if the chair or barstool is not level.
- Do not use a chair or barstool if any parts are broken or missing. This includes screws, fasteners, and feet/glides.
- 3. Do not remove any safety labels.
- 4. Always follow cleaning and maintenance instructions.
- 5. Do not stand on chairs/barstools.
- 6. Adult supervision is necessary if being used by children.
- 7. Do not shake or sway while in use. Keep all four legs on the ground when in use.