




INSTR #320900 rev. E 12/23


Route Stand





Route Stand

- 4 ea. DD8708 86" Split Post W/Thrd Connector
- 1 ea. 1860NC 18" x 60" Wire Shelf (2nd wire shelf is optional can be ordered separately)
- 4 ea. Solid Shelf (DD1310J)










Snap a 2-piece plastic sleeve together around each post on groove #6 to support the bottom shelf. Be sure that the wider part is downward and the bead on the inside of the sleeves snaps into the numbered groove on the post.



Stand the 18" x 60" wire shelf on its side and, working from the bottomside of the shelf, slide the four posts up through the post holes until the plastic sleeves on the posts are seated. Note: the mat wires are on the top of the wire shelf and the collars are thicker at the bottom.



Set the unit upright on the floor and seat each corner of with a rubber mallet or with a hammer and board as shown above. Do this for every shelf.

