

Step-by-Step Guide to Programming Your MX Blender


WARING
COMMERCIAL

BLEND
PREP
COOK
BREW

LARGE SMOOTHIE

Total blend time: 12 seconds
65% speed – 7 seconds
100% speed – 5 seconds



PROGRAM 1 Large Smoothie Recipes





1 To enter new program, press both and buttons simultaneously.




2 Press the program button you wish to set (pick 1–4). In this case, press .



3 Press or button to set speed value. Set to 65%.
Once desired speed is reached, press button to select speed.
NOTE: Time starts at 5 seconds.




4 Use and buttons to set time value (up to 90 seconds). Set to 7 seconds.
Press button to confirm time setting.




5 Press or button to set speed value. Set to 100%.
Once desired speed is reached, press button to select speed.
NOTE: Time starts at 5 seconds.



6 Use and buttons to set time value (up to 90 seconds). Set to 5 seconds.
Press button to confirm time setting.



7 To save the program setting, wait 5 seconds.



8 Press both and simultaneously.





Program 1 is now successfully programmed.

To begin saving additional programs, repeat the same steps above for other recipes.

Step-by-Step Guide to Programming Your MX Blender



Tips & Tricks

1. The  button serves as the ENTER/SELECT button.
2. Press and hold the  or  button to quickly scroll through speeds.
3. Speed can be set between 5% – 100%.
4. Once 90 seconds is reached, pressing  button will not increase the value.
Prompt: MEMORY LIMIT for 2 seconds