

Use & Care Guide

OUTDOOR FOLDING TABLES & CHAIRS



ASSEMBLY/ARRIVAL

1. It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
2. Inspect all parts upon arrival and before use.
3. Test folding mechanism before use.
4. Adult setup is required.
5. Make sure any applicable locks and rings are in correct place before use. Failure to engage all locks and rings may cause personal injury or property damage. As these are misuse, they are not covered under warranty.



STORAGE

1. Cover when not in use or storing long term.
2. Clean before storing.



ONGOING MAINTENANCE

1. Lightly oil folding mechanisms when joints begin to stick, squeak, or become difficult to open or close.



CLEANING INSTRUCTIONS

METAL

1. Clean using a solution of mild soap or detergent with warm water. Recommended: Noble Lemon Lance (147LMNLANRQT).
2. For dried-on dirt, clean with a soft brush and a mild cleaner. Recommended: Noble Spiffy Shine (999SPIFSHINE).
3. Make sure metal is fully dry and clean before use to prevent rusting and other discoloration. As these may be the result of misuse, they may not be covered under warranty.

PLASTIC

1. Clean with mild soap or detergent and water. Recommended Cleaners: Noble Lemon Lance (147LMNLANRQT), and Noble AllSurf (147ALLSRF2HG).
2. Make sure product is fully dry after cleaning and before use.



CAUTION

1. Make sure tables/chairs are stable and balanced before use.
2. When folding use caution to avoid injury to fingers/hands.
3. Do not sit, stand, lean, or jump on tables. Make sure all legs are on the ground before putting things on the table.
4. Do not jump, stand, or lean on chairs. Make sure all four legs are on the ground when in use.
5. Adult supervision is required if used by children.
6. Do not use if parts are broken or missing.