

Use & Care Guide

OUTDOOR UMBRELLAS & BASES



ASSEMBLY/ARRIVAL

1. It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
2. Make sure there are no rips or stains in the umbrella's fabric.



STORAGE

1. Store inside or cover when not in use.
2. Clean and fully dry umbrella before storing.
3. Make sure umbrella is fully closed before storing.



ONGOING MAINTENANCE

1. Umbrella base: Tighten all bolts and connections monthly.



CLEANING INSTRUCTIONS

METAL FRAME

1. Clean using a mild soap/detergent with warm water and a clean cloth. Recommended: Noble Lemon Lance (147LMNLANRQT) and Noble Spiffy Shine (999SPIFSHINE).

WOOD FRAME

1. Clean using a mild soap/detergent with warm water and a clean cloth or soft brush. Recommended Cleaners: Noble Sunbright (147SUNBRIGHT) and Noble Lemon Lance (147LMNLANRQT).

UMBRELLA FABRIC

1. Wipe down any dirt with a soft brush. Get stains out with mild soap/detergent and warm water with a cloth or soft brush. Recommended Detergent: Noble Detergent (147DTRGT22HG).
2. Clean up bird droppings, mold, mildew, pollen, dirt, and dust as quickly as possible.
3. Do not use abrasive cleaners on umbrella fabric or frame.



CAUTION

1. Always make sure umbrella is closed when not in use and during medium-high winds and inclement weather.
2. Make sure any knobs on umbrella base or table are tightened against umbrella pole when in use.
3. Please use caution when opening/closing umbrellas.
4. Do not use/open in case of bad weather – such as heavy rain, wind, etc. It is suggested to store inside during these times. Damage caused by improper storage or operation is considered user error and may not be covered under warranty.
5. Do not use if parts are broken or missing.