

Use & Care Guide

WOODEN CHAIRS, BARSTOOLS & FOLDING TABLES



LANCASTER™
TABLE & SEATING

VINEYARD Series

PREMIUM WOODEN FURNITURE FOR EVENTS



ASSEMBLY/ARRIVAL

1. It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
2. Assembly, if applicable, should be conducted by a qualified adult using the applicable instructions.



STORAGE

1. Store in a clean dry and enclosed location, do not leave outdoors.
2. Folding tables come with storage blankets and u shaped braces in the packaging to use while storing the folding tables
3. If stackable, do not stack higher than recommended and use caution when stacking and unstacking



FOLDING INSTRUCTIONS

2-3 people recommended

TABLES

1. To open, turn the table on its side and rest the side on the u-shaped braces provided. One person should hold the table up and another person can open the table legs and lift the arm braces into the latch. Then slide the pin through the holes to secure into place for both legs. Then 2 people can flip the table into the upright position.
2. To close, 2 people can turn table on to its side and rest the side on the U-shaped braces provided. One person should continue to hold the table in place and another person carefully pulls the pin from the latch and arm brace. Then lay the arm brace flat against the underside of the table while folding the legs down. Finally, repin the arm brace in the latch to secure in the folding position.
3. Store in a clean, dry, and enclosed location.

BENCHES

Open the legs of the bench and lift arm brace into the latch, then slide pin through the holes to secure arm in place, repeat for other leg(s). To close, carefully pull pin from the arm brace and latch. Then lay arm brace flat against the underside of the bench while folding the leg down. Finally, repin the arm brace in the latch to secure in the folded position.



ONGOING MAINTENANCE

1. Use a clean, dry cloth or a soft duster to dust weekly.
2. Inspect all welds and fasteners on tables for damage before use. Ensure all legs are straight and touching the floor.
3. Do not use if any parts are damaged or missing.

MONTHLY

- Tighten all bolts and screws. Ensure structure is sound and there are no cracks/breaks in material. Do not overtighten – this may result in cracks in the material.



CLEANING INSTRUCTIONS

WOOD

1. Do not use abrasive cleaners or products.
2. Use a clean, soft cloth to dust furniture weekly. Dust in the direction of the grain to prevent visible scratching.
3. Clean with a mild soap and damp cloth and dry with a dry cloth. Recommended cleaners: Sunbright (999SUNBRIGHT) and Luster Plus (999LUSTER+).
4. If you are using a new soap or cleaner, test first on an area that isn't visible.
5. Make sure wood is fully dry after cleaning and before use to prevent warping or damage to the finish. As these are the result of misuse, they may not be covered under warranty.

FABRIC CUSHIONS

1. Dirt and dust can be removed using a vacuum.
2. Use a soft, clean cloth to wipe up any spills.
3. If fabric is removable, check if machine washable. If not, spot clean. Recommended: Noble Vanish 999VANISH, Detergent: Noble Detergent 147DTRGT22HG.
4. Before cleaning, test a piece of fabric that isn't visible with soap/detergent to ensure that it will not stain fabric.



CAUTION

1. Do not use a chair/barstool/table if any parts are broken or missing. This includes screws, fasteners, and feet/glides.
2. Do not remove any safety labels.
3. Always follow cleaning and maintenance instructions.

CHAIRS/BARSTOOLS/BENCHES

- Do not stand on chairs/barstools/tables.
- Children should always be supervised by an adult whenever they are using this furniture. Do not shake or sway while in use. Keep all four legs on the ground when in use.
- When using zippers, take care to prevent fabric from catching.