

Wind Sign II & Wind Sign Deluxe





www.plasticade.com

Snap Frame Assembly Instructions

See Reverse Side for
Quick-Change™ Frame Instructions

Hardware Provided



1. Lay frame on its side and base on end as shown
 2. Place washer on bolt fastener
 3. Insert bolt fastener through hole in bottom of base
 4. Align spring assembly with bolt fastener
 5. Screw bolt fastener into bottom of corresponding spring assembly, tighten
 6. Repeat for second bolt fastener, washer, and spring assembly
 7. Turn sign frame upright, with base flat on the ground
- (The Allen Wrench is not needed for the assembly of the Snap Frame)

Sign Insertion Instructions


CAUTION: Sign Substrate should weigh
no more than 5 lbs. per side.

Instructions for Filling Base with Sand


Rest wheel side of base on step or block.
Unscrew cap from fill hole and pour dry sand into
base. Fill with sand to achieve desired wind
resistance. Sand should be level inside of base
to maintain optimum balance. Shake gently to
level sand.

To Obtain Desired Wind Resistance Use Chart


Pounds of Ballast	Head-on Wind Resistance
70 lbs.	40 mph
100 lbs.	55 mph
115 lbs.	60 mph
130 lbs. maximum	



1. Snap open all four side rails*



2. Remove Clear Protective
Cover from frame



3. Place poster in frame,
inserting poster
corners into the four
corner slots



4. Place clear protective
poster cover in frame,
inserting cover corners
into the four corner slots



5. Snap close all four
side rails*



**PINCH POINT
KEEP
HANDS CLEAR**

*** WARNING: Use caution when
you snap rails open and close**

To move sign stand from
place to place - grab frame,
tilt stand back on wheels,
and push sign to move it.

