

# Use & Care Guide

## WOOD TABLE TOPS



LANCASTER™  
TABLE & SEATING



### ASSEMBLY/ARRIVAL

1. It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
2. Inspect table top for damage before use.
3. Do not remove any safety labels.
4. Always follow cleaning and maintenance instructions.



### STORAGE

1. After assembly, do not store upside down.



### ONGOING MAINTENANCE

1. It is recommended to use placemats and coasters to prevent scratches, scrapes, and warping.
2. Do not place hot items directly onto wooden tabletops. They may damage the finish. As this is the result of misuse, it may not be covered under warranty.



### CLEANING INSTRUCTIONS

1. Do not use abrasive cleaners or products.
2. Use a clean, soft cloth to dust furniture weekly. Dust in the direction of grain to prevent visible scratching.
3. Clean with a mild soap and damp cloth and dry with a dry cloth. Recommended Cleaners: Noble Sunbright (999SUNBRIGHT) and Noble Luster Plus (999LUSTER+).
4. If you are using a new soap or cleaner, test first on an area that may not be shown.
5. Make sure wood is fully dry after cleaning and before use to prevent warping or damage to the finish. As these are the result of misuse, they may not be covered under warranty.



### CAUTION

1. Always make sure table is stable and balanced.
2. Avoid scraping with sharp items/utensils.
3. Do not use if table top is broken or damaged.

