


Wood Top Work Tables With Cross Bracing

Assembly Instructions



TOOLS REQUIRED

- (1) 4mm HEX Wrench (Included)
- (1) 3/8" Socket Wrench

HARDWARE:

- (16) 1" Lag Screws

4 Leg Table

PARTS:

- (1) Wood Top
- (4) Leg Gussets
- (4) Legs
- (2) End Bracing Socket
- (2) Corner Bracing Socket
- (2) Side Bracing
- (1) Rear Bracing

6 Leg Table

PARTS:

- (1) Wood Top
- (6) Leg Gussets
- (6) Legs
- (3) End Bracing Socket
- (2) Corner Bracing Socket
- (3) Side Bracing
- (2) Rear Bracing

Assembly Instructions

1. Make sure the assembly area is clean and on a flat secure surface. Carefully remove all the contents within the box. Place the wood top face down on a rug, carton or other protected surface.
2. Using a socket wrench and the provided 1" lag screws, attach the leg gussets to the pre-drilled holes in the wood top. It is recommended that the gussets be turned so the set screws are positioned toward the center of the table.
3. Adjust bracing sockets to the desired height on the legs and tighten the set screws using the provided hex wrench. Do not overtighten.
4. Slide the side bracing and rear bracing into bracing sockets and tighten the set screws.
5. Loosen the set screws on the leg gussets to allow the legs to be inserted. Place the completed base assembly into the leg gussets and tighten the set screws. Do not overtighten.
6. For the table to be NSF Certified, you must fill all the set screws with silicon caulk.
7. With assistance, grasp the table by the top and turn the table right side up. Adjust the feet to level the table. The table is now ready to be used.

